

Thanks for trying our products! We know you'll love G2 quality and innovation.

Here is our full range of G2 products. To order or learn more, please log on at www.g2ergo.com.



Quick-Turn Throttle Tube
Opens faster than stock!



Billet Replacement Throttle Tube
2 piece design allows cam adjustability!



Competition Handguard System
Unique clamp design allows better cable routing!!



Nylon Bar End Mount Kit
Best handguard mounts...period!



Billet Grip Protector
Stop changing grips after every wipe-out!



Control Perch Spacer
Improved lever fit for big hands!

G2 Plastic Hand Shields (Installation instructions)

FOR USE AS REPLACEMENT HAND SHIELDS ON G2 MOTO HAND SHIELDS

Remove old plastic hand shields by removing two screws. Install replacement Plastic Hand Shields using two screws.

FOR USE AS HAND SHIELDS ON ALUMINUM HAND GUARD

- 1) For best results, install aluminum handguards (not included) to handlebar.
- 2) Plastic Hand Shields have two holes pre-drilled on inner side. A third hole needs to be drilled (using included drill bit) in line with existing holes approximately 1-3 inches from outside of guard.
- 3) Position guard against aluminum handguard in desired location. Using guard as template, mark locations of three holes on aluminum handguard.
- 4) Using included drill bit, drill holes in aluminum handguard in marked locations.
- 5) Attach shield to aluminum handguard using included self-tapping screws. Repeat on opposite side.

For more detailed installation tips, check out

www.G2ergo.com

G2 ERGONOMICS CORP WILL NOT BE RESPONSIBLE FOR IMPROPER INSTALLATION OR USAGE OF THIS PRODUCT. Please follow all instructions provided. If you are unsure of any installation procedure, please contact your local motorcycle dealer.